


Model G0556/G0557 Parts Breakdown



Model G0556/G0557 Parts List

REF	PART #	DESCRIPTION
1	P0556001	APRON (G0556)
1	P0557001	APRON (G0576)
2	P0556002	SHAFT (G0556)
2	P0557002	SHAFT (G0557)
3	P0556003	BODY (G0556)
3	P0557003	BODY (G0557)
4	P0556004	HOLD DOWN ASSY. (G0556)
4	P0556004	HOLD DOWN ASSY. (G0557)
5	P0556005	UPPER ECCENTRIC
5-1	P0556005-1	HANDLE M6-1 X 1-3/4
6	P0556006	CONNECTING BLOCK
7	PW03M	FLAT WASHER 6MM
8	PSB04M	CAP SCREW M6-1 X 10
9	PN02M	HEX NUT M10-1.5
10	P0556010	TURNBUCKLE
11	PN02M	HEX NUT M10-1.5
12	P0556012	BUSHING
13	P0556013	LOWER RIGHT ECCENTRIC
14	P0556014	SCREW ROD

REF	PART #	DESCRIPTION
15	P0556015	HANDLE
16	P0556016	PIN SHAFT
17	P0556017	SPLIT PIN
18	PSS01M	SET SCREW M6-1 X 10
19	PK47M	KEY 4 X 4 X 15MM
20	P0556020	BUSHING
21	P0556021	SMALL SHAFT
22	P0556022	LOWER LEFT ECCENTRIC
23	P0556023	T-NUT
24-1	P0556024-1	FINGER 1"
24-2	P0556024-2	FINGER 2"
24-3	P0556024-3	FINGER 3"
24-4	P0557024-4	FINGER 4" (G0557)
25	PSB14M	CAP SCREW M8-1.25 X 20
26	P0556026	SAFETY GLASSES LABEL
27	P0556027	PINCH HAZARD LABEL
28	P0556028	READ MANUAL LABEL
29	P0556029	MACHINE ID LABEL (G0556)
29	P0557029	MACHINE ID LABEL (G0557)

