


G6050 PART BREAKDOWN



REF	PART #	DESCRIPTION
01A	P6048007A	BUTTON HD CAP SCR
02A	P6050002A	EXHAUST COVER
04	P6050004	PU WASHER
05A	P6050005A	CAP SCREW + SW
06	P6050006	CAP
07A	P6044077	FLAT WASHER
08	P6050008	SPACER
09	P6050009	PISTON STOPPER
10	P6050010	SPRING
11	P6050011	O-RING
12	P6050012	PISTON HEAD VALVE
12-1	P6050012-1	SPACER
13	P6050013	O-RING
14	P6050014	SEAL
15-2	P6050015-2	O-RING
15A	P6050015A	OIL-LESS RING ASSY
16B	P6050016B	PISTON ASSEMBLY
19	P6050019	O-RING
20	P6050020	O-RING
21A	P6050021A	CYLINDER
21-1	P6050021-1	O-RING
22	P6050022	UPPER BUMPER
23	P6050023	GASKET
24	P6050024	BODY
25	P6050025	BOTTOM BUMPER
26	P6050026	O-RING
27	P6050027	NOSE
28A	P6050028A	CAP SCREW
29A	P6050029A	STEPPED PIN
30A	P6048030A	PU RING
31A	P6050031A	BUTTON HD CAP SCR
32	P6050032	SAFETY LEVER
33	P6050033	SPRING
34	P6050034	SAFETY LEVER
35A	P6050035A	CAP SCREW
36	P6050036	SPRING
37A	P6050037A	SAFETY LEVER ASSY
38A	P6050038A	SPRING GUIDE
39	P6050039	LOCK NUT
40	P6050040	RUBBER PAD
41	P6050041	O-RING

REF	PART #	DESCRIPTION
42	P6050042	PLUNGER
43	P6050043	VALVE
44	P6050044	O-RING
45	P6048045	O-RING
46	P6050046	O-RING
47	P6044047	VALVE PLUNGER
48	P6050048	O-RING
49	P6048049	SPRING
50	P6050050	PLUNGER
51	P6050051	O-RING
52	P6050052	PLUNGER CAP
53	P6050053	TRIGGER ASSY
56	P6050056	PUSHER
57	P6050057	STOPPER
58	P6050058	SPRING
59	P6050059	GASKET
60A	P6050060A	SET PIN
61A	P6050061A	CAP SCREW
62	P6050062	SPIRAL SPRING
63	P6050063	ROLLER
64	P6050064	BALL PIN
65	P6050065	MAGAZINE
66	P6050066	NAIL GUIDE LINER
67A	P6050067A	CAP SCREW
68A	P6050068A	DEBRIS SHIELD
69	P6050069	FLAT WASHER
71A	P6050071A	INSERT
73	P6050073	BRACKET
74A	P6050074A	LOCK NUT
76	P6050076	SET PLATE
77	P6050077	SET PLATE
78	P6050078	BUTTON HD CAP SCR
80A	P6050080A	AIR PLUG
82	P6050082	FLAT WASHER
83A	P6050083A	GASKET WASHER
84	P6050084	STEPPED PIN
85	P6050085	SPACER
88	P6050088	SPRING WASHER
90	P6050090	BRACKET
92A	P6044077	FLAT WASHER
93	P6050093	RUBBER PAD